

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A.*

C-A OPERATIONS PROCEDURES MANUAL

ATTACHMENT

4.120.10.a 10 O'Clock (PEER 15) Critical Device & Permit Link Tests

C-A-OPM Procedures in which this Attachment is used.		
4.120.10		

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: Signature on File _____
 Collider-Accelerator Department Chairman _____ Date _____

V. Castillo

4.120.10.a 10 O'Clock (PEER 15) Critical Device & Permit Link Tests

PASS ANNUAL ACCEPTANCE TEST PROTOCOL

Division A Software Filename and Checksum: Title: _____ Checksum: _____

Division B Software Filename and Checksum: Title: _____ Checksum: _____

Initial testing complete:

Test Team Leader's Name (Print): _____ Life Number: _____

Test Team Leader's Name (Sign): _____ Date: ____/____/____

Acceptance test procedure complete (following repairs and retesting if required):

Test Team Leader's Name (Print): _____ Life Number: _____

Test Team Leader's Name (Sign): _____ Date: ____/____/____

Test results reviewed by:

Safety Section Head's Name (Print): _____ Life Number: _____

Safety Section Head's Name (Sign): _____ Date: ____/____/____

Test results accepted by Radiation Safety Committee:

RSC Member's Name (Print): _____ Life Number: _____

RSC Member's Name (Sign): _____ Date: ____/____/____

1.1 Setup and test of Critical Devices and Permit Link response to a loss of PASS enable

<input type="checkbox"/>	SET	CD Key switch for	XY ARC
<input type="checkbox"/>	VERIFY	CD Key switch is set for	XY ARC
<input type="checkbox"/>	PLACE	Peer 15 in Mode 8	
<input type="checkbox"/>	VERIFY	Peer 15 is in Restricted Access	MODE 8
<input type="checkbox"/>	VERIFY	MCR sees RHIC Inj. CD on CD page	DISABLED
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Injn inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/>	ON
<input type="checkbox"/>	VERIFY	MCR sees RHIC ring CD , (B/S 1,2, & 3) on CD page	DISABLED
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC ring inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS 1&2)	ON
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Rchback latch Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS3)	OFF
<input type="checkbox"/>	VERIFY	MCR sees RHIC Permit Link Div A <input type="checkbox"/> & Div B <input type="checkbox"/>	DISABLED
<input type="checkbox"/>	PLACE	Peer 15 in Mode 16	
<input type="checkbox"/>	VERIFY	Peer 15 is in Controlled Access	MODE 16
<input type="checkbox"/>	VERIFY	Peer 15 gate: 11GS1 is	CLOSED
	RESET	Peer 15 gates: 9GS1, 9EL1, 9GI1, 9ED1, 10GE1, 10GI1, 10EL1, 10ED1	
<input type="checkbox"/>	VERIFY	Peer 15 gates: <input type="checkbox"/> 9GS1, <input type="checkbox"/> 9EL1, <input type="checkbox"/> 9GI1, <input type="checkbox"/> 9ED1, <input type="checkbox"/> 10GE1, <input type="checkbox"/> 10GI1, <input type="checkbox"/> 10EL1, <input type="checkbox"/> 10ED1 are	RESET
<input type="checkbox"/>	SWEEP	Peer 15 Zones: 9Z1, 10Z1, 10Z2	
<input type="checkbox"/>	VERIFY	Peer 15 Zones: <input type="checkbox"/> 9Z1, <input type="checkbox"/> 10Z1, <input type="checkbox"/> 10Z2 are	SWEPT
<input type="checkbox"/>	PLACE	Peer 15 in Mode 24	
<input type="checkbox"/>	VERIFY	Peer 15 is in No Access	MODE 24
<input type="checkbox"/>	VERIFY	MCR sees RHIC Inj. CD on CD page	DISABLED
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Injn inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/>	OFF
<input type="checkbox"/>	SET	RHIC Primary Beamstop command	OUT
<input type="checkbox"/>	VERIFY	RHIC Primary Beamstop command is	OUT
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC ring CD , (B/S 1,2, & 3)	DISABLED
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC ring inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS 1&2)	OFF
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Rchback latch Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS3)	OFF
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Permit Link Div A <input type="checkbox"/> & Div B <input type="checkbox"/>	ENABLED
	TURN	Any key in the RHIC Key Tree	
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 go to	MODE 2
<input type="checkbox"/>	VERIFY	MCR sees RHIC Inj. CD on CD page	DISABLED
<input type="checkbox"/>	VERIFY	MCR sees Peer 15 RHIC Injn inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/>	ON

- | | | | |
|--------------------------|---------------|--|-----------------|
| <input type="checkbox"/> | VERIFY | MCR sees RHIC ring CD , (B/S 1,2, & 3) on CD page | DISABLED |
| <input type="checkbox"/> | VERIFY | MCR sees Peer 15 RHIC ring inhibit Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS 1&2) | ON |
| <input type="checkbox"/> | VERIFY | MCR sees Peer 15 RHIC Rchback latch Div A <input type="checkbox"/> & Div B <input type="checkbox"/> (BS3) | OFF |
| <input type="checkbox"/> | VERIFY | MCR sees Peer 15 RHIC Permit Link Div A <input type="checkbox"/> & Div B <input type="checkbox"/> | DISABLED |
| | PLACE | Peer 15 in Mode 8 | |
| <input type="checkbox"/> | VERIFY | Peer 15 is in Restricted Access | MODE 8 |
- ☐ **Check for acceptance of Setup and test of Critical Devices and Permit Link response to a loss of PASS enable.**

END OF TEST PROCEDURE

TTL: Sign for completion of initial testing: _____

Date: ____/____/____

TTL: Sign for completion of final testing: _____

Date: ____/____/____